

Firemongery Fitting Your Hinges- IH-HINGE-SS201-FIRE-SQUARE-SSS- 3P

To make sure everything meets fire safety standards, it's important to use the right amount of intumescent material provided in your kit when fitting the hinges and locks.

For the Butt Hinges:

Each door needs 3 hinges – and the intumescent pads included in your Firemongery kit are designed to help you fit them correctly.

You'll find 2 packs, each containing 6 pieces of 1mm thick intumescent pads.

Now, here's how much to use depending on your doorset type:

FD30 Doorset (30-minute fire rating):

- Use 1 piece of intumescent pad on each side of the hinge – one between the hinge and the door, and one between the hinge and the frame.

- That's 2 pieces per hinge, so you'll use 6 pieces in total (just 1 pack).

FD60 Doorset (60-minute fire rating):

- The requirement doubles here. Use 2 pieces between the hinge and the door, and 2 pieces between the hinge and the frame.

- That's 4 pieces per hinge, meaning you'll need 12 pieces in total – or both packs.

