

Step 1: Prepare the Intumescent

- Pop out the two circles and two keyhole shapes from the intumescent sheet – you won't need these, so go ahead and discard them.

For FD30 Doorsets:

- Peel off the self-adhesive backing from the main body piece.
- Wrap it around the lock case, making sure the round holes line up with the spindle (the part where the handle goes through).
- Make sure the back, top, and bottom of the lock case are all fully covered.
- Take the second piece of intumescent and place it behind the strike plate (on the door frame).

For FD60 Doorsets

(extra fire protection)

Follow all the FD30 steps above, plus:

- You'll find two extra pieces of intumescent – these go behind the forend of the lock case (the flat front face).
- There's also an extra strike plate piece – fit this behind the strike plate, especially at the screw fixing points.
- This will double up the intumescent thickness behind both the lock forend and the strike plate for added fire protection.

