





CYLINDERS MAINTENANCE GUIDE


To maintain this product's appearance, simply wipe over with a lemon based very mild soap solution and a soft cloth once a month or every 2 weeks in areas of high sea salt such as coastal areas.

DO NOT:

Wipe over with a strong cleaning detergent or any cloths which may scratch the surface of the cylinder.

 Wipe highlighted area

 Lubricate highlighted area with silicon based oil or graphite



To register your guarantee, please visit
www.uapcorporate.com/register

The cylinder comes with a key fob which includes a serial number. Customers can register the cylinder on our website to activate their 2 year guarantee.

Registering is simple. If you are registering a UAP cylinder, on your cylinder keys will be a key ring. Simply enter the serial number on the key ring and fill out your details.