



Concealed Door Closers

Solid brass anchor plates, powder coated mechanism housing and precision-engineered chain add to its appeal. Supplied with fixing screws and full fitting instructions.

CLEANING

The closers should be cleaned monthly with a moist cloth. At no point should any form of cleaning agents be used.

The internal workings of the door closer should be lightly sprayed with a silicone lubricant (or similar) every 12 weeks. A suitable, widely available product is GT85. Dry graphite maintenance powder is a suitable alternative. Do not use WD-40 or oil based lubricants as these may attract debris.

It's very easy to do. If you are using GT85, spray it into your product whilst moving doors in and out several times.

Doing so will maintain your guarantee and keep your closer operating smoothly. If you are using dry graphite maintenance powder, follow the instructions provided. Wipe away any excess oil or graphite, and then move onto the next door.

DO NOT:

Wipe over with a strong cleaning detergent or any cloths which may scratch the surface of the cylinder.

 Wipe highlighted area

 Lubricate highlighted area with silicon based oil or graphite

